

Template Instructions for Bent and Continuous Curved Rods

Templates are required for all Bent and Curved Rods

- Butcher Paper or Kraft paper is recommended and may be pieced together.
- Templates **MUST** be actual full-size pattern of the window/wall.
- Select the Window Style shown on the Template Worksheet that most closely represents your window.
- Provide all measurements and degree of angles requested on the worksheet. Measurements must be noted on the template in addition to the worksheet.
- Preferred method is to make template on the floor (Top View). If the template is made from the ceiling it must be clearly marked “Bottom View” and noted on the worksheet.

Instructions and Information to include:

- Unless stated differently, measurements given are wall measurements and the factory will make allowances.
- Provide Return Measurement. For double rod sets include the return for front and back rod.
- Must provide degree of angle for all bent rods. Select Drapery Hardware Angle Measuring Protractor is available. (PRO-2016)
- Mark on the template both ends of the rod.
- If rod is to be spliced indicate desired placement of splice.
- Note Company Name and Order # on the template.

Special Notations:

- Off Center or Multiple Masters Rods – mark location where masters are to meet.
- Pocket/Soffit installation – provide pocket depth to insure rod and drapery will fit. If drapery is to hang below the pocket note the height of the pocket.
- Templates made from ceiling **must be labeled “Bottom View”** on the template and worksheet.
- Note on template any specific additional requirements.

Shipping Instructions:

- Roll the template and place in a shipping tube along with the worksheet.
- Ship FedEx or UPS to designated location.
- Contact Customer Service for shipping address.

Bent Rods for Curved Windows



Bent Rods for Angled Windows Corner, Bay, and Recess

